


eCube Plant RNA Mini Kit

*** Things to do before starting**

1. Pipet a required volume of XPRB Buffer or XPPRB Buffer to another RNase-free container and add 10ul β -mercaptoethanol (β -ME) per 1ml XPRB or XPPRB Buffer before use.
2. For 50preps, add 60ml ethanol (96-100%) and for 200preps, add 250ml ethanol (96-100%) to Wash Buffer 2. For 300preps, add 200ml ethanol (96-100%) to each Wash Buffer 2 when first open.
3. All centrifuge steps are done at full speed (**14,000 rpm or 10,000 x g**) in a microcentrifuge.

Grind the Plant Sample (up to 100mg)



eCube Plant RNA Mini Kit

*** Things to do before starting**

1. Pipet a required volume of XPRB Buffer or XPPRB Buffer to another RNase-free container and add 10ul β -mercaptoethanol (β -ME) per 1ml XPRB or XPPRB Buffer before use.
2. For 50preps, add 60ml ethanol (96-100%) and for 200preps, add 250ml ethanol (96-100%) to Wash Buffer 2. For 300preps, add 200ml ethanol (96-100%) to each Wash Buffer 2 when first open.
3. All centrifuge steps are done at full speed (**14,000 rpm or 10,000 x g**) in a microcentrifuge.

Grind the Plant Sample (up to 100mg)

